














ELECTRICITY NETWORK LEGEND






HV Overhead Switch (RED)

-  HVAirBreakSwitch
-  HVDropOutFuse
-  HVDropOutFuse_Sparkless
-  HVGasSwitch
-  HVOverheadBond
-  HVOverheadLinks
-  HVRecloser
-  LoadBreakSwitch






LV Overhead Switch (GREEN)

-  <all other values>
-  FuseSwitchDisconnecter
-  LVAirBreakSwitch
-  LVOverheadLinks
-  LVServiceLinks



HV Ground Level Switch (RED)

-  <all other values>
-  HVFuse
-  HVSwitch
-  HVIsolator
-  HVCircuitBreaker




LV Ground Level Switch (GREEN)

-  <all other values>
-  LVFuse
-  LVPillarLinks
-  LVCircuitBreaker
-  LVSubLinks







StreetLight

-  <all other values>
-  Streetlight



Distribution Enclosure

-  Stockade
-  Chamber
-  CablePit



LVPillar (BLACK)

-  LVDistributionBox
-  LVLinkPillar
-  LVPOEBox
-  LVMicroPillar
-  LVServicePillar
-  StreetlightCubicle



Switch Gear Device

-  HVSwGear (RED)
-  LVSwGear (GREEN)



LV Service Points (GREEN)

-  LVServiceMeter
-  LVServiceNominalLocation



Other LV Service Points

-  <all other values>
-  Misc Service Points




HV Overhead (RED)

-  <all other values>
-  HVDistributionOH




HV Underground (RED DASH)

-  <all other values>
-  HVDistributionUG



LV Overhead

-  <all other values>
-  LowVoltageOH (GREEN)
-  ServiceOH (YELLOW)



LV Underground

-  <all other values>
-  LowVoltageUG (GREEN DASH)
-  ServiceUG (YELLOW DASH)




SL Overhead (BLUE)

-  <all other values>
-  StreetlightingOH






SL Underground (BLUE DASH)

-  <all other values>
-  StreetlightingUG

Distribution Support Structure

-  DistPole
-  StayPole
-  OtherPole

SUBSTATION (BLACK)

-  Kiosk
-  Padmount
-  SwitchCubicle
-  TwoPoleSub
-  OnePoleSub

StreetLight Column

-  SLColumn
-  SLDistColumn
-  HighMast
-  TeleCommSLMast

IMPORTANT NOTE: The term 'ABANDONED' is utilised to identify an underground cable that has been physically disconnected from the ActewAGL electricity network, is not in service and cannot readily be put back into service without specific augmentation and/or reconnection works. Cable(s) identified by ActewAGL as 'ABANDONED' have been discarded in-situ by ActewAGL. ALL cables should be treated as 'LIVE' and Dangerous until proven de-energised and safe.

All network distribution data is the property of ActewAGL and no warranty as to the accuracy or completeness of the information is provided. No liability for any loss or damage arising from the use of this information will be accepted. Copyright (c) ActewAGL 2009

ActewAGL